



Technical Bulletin # 132

RE: EVERWHITE 932 and COLORSET 931 Epoxy Grout Maintenance
REVISED: June 8, 2009

EVERWHITE 932 and COLORSET 931 Epoxy Grout Maintenance

Purpose: To safely maintain a clean epoxy grout and tile/stone surface and to preserve the installation's beauty and integrity.

These recommendations are intended as general guidelines. Always read cleaning product directions thoroughly prior to use. Always test new cleaners in an inconspicuous area. Acidic cleaners are not recommended for any type of stone.

Keep surfaces clean and dry to reduce possibility of slip-fall accidents.

Procedure:

1. Sweep, dust mop or vacuum surface.
2. Mix, apply and rinse per product directions.
3. Spot cleaning of the grout and tile should be done as spills or soiled areas occur.

Routine Maintenance - Routine cleaning of the grout and tile surface on a daily or weekly schedule should be done with potable water or a pH neutral cleaner such as C-Cure Grout and Tile Cleaner with a string or sponge mop. Optionally, a low speed floor machine with white pads or soft brushes may be used.

Routine Spray & Wipe – Routine Spray cleaning with an C-Cure Grout and Tile Cleaner or a neutral pH spray-and-wipe citrus cleaner.

Periodic Heavy-Duty - Countertops, Floors & Walls

Use C-Cure Heavy-Duty Cleaner & Stripper. Excellent for neglected grout joints. Contains no acid.

***Antibacterial/Disinfectant –**

No-rinse, enzymatic, antibacterial or disinfectant cleaners may be used only after proper dilution with potable water per manufacturer instructions. Concentrated solutions of no-rinse/enzymatic cleaners are not recommended for prolonged exposure on epoxy grout surfaces. Discoloration or damage to the epoxy grout may occur.

C-Cure Technical Assistance:

Call 800-895-2874

Visit our website at www.c-cure.com.

Technical Bulletin #132-TB-1208

Notice: The information in this bulletin is presented in good faith, but no warranty, express or implied, is given nor is freedom from any patent in as much as any assistance furnished by C-Cure with reference to the safe use and disposal of its products is provided without charge, C-Cure assumes no obligation or liability therefore, except to the extent that any such assistance shall be given in good faith.